



PRIOR ART

FIG. 1




200

FIG. 2



300

FIG-3



(A)
FIG. 4a






FIG. 4b



501

FIG. 5a



551

FIG. 5b




FIG. 6

```

module Example_Embodiment (clk, clken, reset, phase, in, pwm);
    parameter WIDTH = 24;          // Data path width
    parameter FACTOR = 8;          // log2 of the divider in the ftr
    parameter PWMW = 4;           // The number bits in the PWM
    parameter MI = WIDTH - 1;      // Max index of bus
    parameter RST_TO = (1 << MI); // Reset state..
    input clk;                     // Main clock
    input clken;                   // A clock enable qualifier: Fclk is
                                // this enable expected to be about
                                // (16*32*Fs) = 24Mhz approx.

    input reset;                   // Initialize asynchronous
    input [PWMW:0] phase;          // PWM Phase control
    input [MI:0] in;               // The input audio data
    wire [MI:0] sin;               // The input scaled to -1.16db (7/8)
    output pwm;                    // The output pwm bit
    reg pwm;
    wire pwma;                     // Internal asynchronous pwmbit
    wire [MI:0] fb;                // Feedback quantity..
    wire [WIDTH:0] err;            // Error signal from differencer
    wire [MI:0] serr;              // Scaled error value
    reg [MI:0] int;                // Integrator in FB loop...
    wire [WIDTH:0] sum;            // The actual sum prior to clip
    wire [MI:0] nxt_int;           // Next state of clipped integrator
    wire [MI:0] nxt_int1;          // Intermediate next state
    wire force_all_one;            // Overflow and underflow bits
    wire force_all_zero_b;

    // The forward path through the PWM to the output stream:
    pwm # (WIDTH, PWMW) pwmi (clk, clken, reset, phase, int, pwma);
    // The feedback path through the filter:
    ftr # (WIDTH, FACTOR) ftri (clk, clken, reset, pwma, fb);
    // This is one example way to clip an integrator - namely, process one
    // extra bit and look for a difference in the extra bit and the
    // sign bit like this.
    assign #3 sum = {serr[MI], serr}
                  + {int[MI], int};
    assign #0 force_all_one = sum[MI] & ~sum[MI+1]; // Hi => OVF
    assign #0 force_all_zero_b = (sum[MI] | ~sum[MI+1]); // Lo => UFL
    // This next line forces the nxt_dout1 bus to all 1 if force_all_one
    // is true, forces it all 0 if force_all_zero_b is false...
    assign #0 nxt_int1 = ( {~sum[MI], sum[MI-1:0]}
                          | {WIDTH{force_all_one}}
                          & {WIDTH{force_all_zero_b}} );

    // .. and then just make the signed version..
    assign #0 nxt_int = {~nxt_int1[MI], nxt_int1[MI-1:0]};
    // Create the reduced amplitude input: in some cases, it may be advantageous
    // to drop the signal so that peaking at 15k is not distorted..
    assign #0 sin = in - {{3{in[MI]}}, in[MI:3]}; // ie in - 1/8 in
    // Now create the integrator in the loop .. first assign the
    // error gain: in this case, about 3/32
    assign #1 err = sin - fb;
    assign #1 serr = {{4{err[MI]}}, err[MI:4]} // ie 1/16
                   + {{5{err[MI]}}, err[MI:5]}; // + 1/32
    always @(posedge clk or posedge reset)
        if (reset)
            begin
                int <= RST_TO;
                pwm <= 1'b0;
            end
        else if (clken)
            begin
                int <= nxt_int;
                pwm <= pwma;
            end
        end
endmodule // Example_Embodiment

```

FIG. 7a


```

// ===== PWM CELL =====
// This is an example cell that accepts a parallel input bus and creates the
// output PWM stream...
module pwm (clk, clken, reset, phase, in, out);
    parameter WIDTH = 16;          // Data path width
    parameter PWMW = 4;            // The number bits in the PWM
    parameter MI = WIDTH - 1;      // Max index of bus
    parameter PI = PWMW - 1;       // Max index of phase bus
    parameter PMAX = ((1 << PWMW) - 1); // Max phase count
    input      clk;                // Main clock
    input      clken;              // A clock enable qualifier: Fclk is
                                // this enable
    input      reset;              // Initialize asynchronous
    input [MI:0] in;               // The input state
    output     out;                // The output state
    input [PWMW:0] phase;          // This is used to allow the clk to
                                // run faster than the BRM so that
                                // the multi levels are converted
                                // to pulse widths. The MSB
                                // controls the odd/even phase, the
                                // other bits the PWM

    wire [PI:0] pwm;               // Pulse width required..
    wire        pwmi;              // .. increment by one of above
    wire [PI:0] sum;               // Temporary - used in PWM..
    wire        pmax;              // Phase MSB is about to change
    wire        pdoe;              // Enable to the pdo
    // Asynchronously find when the phase MSB is about to change:
    assign      pmax = (phase[PI:0] == PMAX) ? 1 : 0;
    // Enable the pdo only when the phase MSB is about to change and
    // when the input is enabled - this generates the pdo clken signal:
    assign      pdoe = pmax & clken;
    // Modulate the input bus into the to the PWM Width using something
    // very similar to the pdo cell again, but note that this generates
    // an output bus of width PWM width (and note this only runs at a
    // fraction of the input clock rate)..
    pdow #(PWMW, WIDTH) pdop(clk, pdoe, reset, in, pwm, pwmi);
    // Now generate the pulse output by comparing the phase
    // count to the multi-bit output, however this comparison depends
    // upon the phase MSB.. Lisp code for reference:
    // (if (<= (if MSB (1+ phase) (- dith phase)) pwm) 1 -1)
    // A simple equivalent can be found by looking at the carry
    // output of the following expression:
    assign {out,sum} = ({PWMW{phase[PWMW]}} ^ phase[PI:0])
                    + pwm + pwmi;
    // Thus the output variable (out) is asynchronous - it occurs
    // shortly after the clock.
endmodule // pwm

```

FIG. 7b

```

// ===== FILTER CELL =====
// This is an example filter cell for the Example_Embodiment application,
// which includes a single bit in the feedback input. It's a
// simple IIR single pole filter like this:  $y \leq y + a(x-y)$  where  $a$  is
//  $1/(2^{\text{FACTOR}})$ 
module ftr (clk, clken, reset, in, out);
    parameter WIDTH = 16; // Data path width
    parameter FACTOR = 9; // The log2 of the divider
    parameter MI = WIDTH - 1; // Max index of bus
    input clk; // Main clock
    input clken; // A clock enable qualifier: Fclk is
                // this enable
    input reset; // Initialize asynchronous
    input in; // The input state
    output [MI:0] out; // The output state
    reg [MI:0] out;
    always @(posedge clk or posedge reset)
        if (reset)
            begin
                out <= 0;
            end
        else if (clken)
            begin
                out <= out
                    - {{FACTOR{out[MI]}}}, out[MI:FACTOR]}
                    + {{FACTOR+1{~in}}, {MI-FACTOR{in}}};
            end
    end
endmodule // ftr

```

FIG. 7c

```

// ===== PDOW CELL =====
// This cell is essentially a first order  $\Sigma\Delta$  modulator - it creates
// an output word (out) and a bit (inc) indicating the word should be
// incremented by one to minimize the noise. There is one other
// circumstance to attend to here - the 'in' may be clocked at
// a rate that differs from this clock so that the following registers the input on
// the enabled clock of this cell..
module pdow (clk, clken, reset, in, out, inc);
    parameter M = 4;           // The number of bits that are
                                // "dithered"
    parameter N = 16;          // The width of the input number
    parameter NI = N - 1;      // Max index needed in width N
    parameter MI = M - 1;      // Max index needed in width M
    parameter ME = NI - M;      // max index of the residue: this is
                                // the max index of the quantity
                                // that is accumulated in the
                                // modulo N error accumulator
    parameter RS = N - M;      // The amount to right shift the din
                                // bus
    input          clk;         // Main clock
    input          clken;       // A clock enable qualifier: Fclk is
                                // this enable
    input          reset;       // Initialize asynchronous
    input [NI:0]   in;          // The input state
    reg [NI:0]     rin;         // Registered input state
    output [MI:0]  out;         // The output state
    output         inc;         // The SD bit itself
    reg [ME:0]     state;       // The local state of the modulo n error
    wire [ME:0]    state_nxt;   // next state of the modulo n error
    // Just add the LSBs of the input to the running total in state,
    // allow state to overflow and keep track of the overflow bit in
    // the inc wire:
    assign {inc,state_nxt} = {1'b0,state} + {1'b0,rin[ME:0]};
    // The output is just the msbs that are not being accumulated in
    // the state, plus 1 if the state has overflowed - as indicated in
    // the inc bit...
    assign out = {-rin[NI],rin[NI-1:RS]};
    // clock like this:
    always @(posedge clk or posedge reset)
        if (reset)
            begin
                state <= 0;
                rin <= 0;
            end
        else if (clken)
            begin
                rin <= in;
                state <= state_nxt;
            end
        end
endmodule // pdow

```

FIG. 7d




FIG. 8




FIG. 9




FIG. 10